

PreFormed™ Curb Overlay Installation Instructions

1.0 PRODUCT & MATERIALS

- 1.1 Product: Curb Overlays are made from high-density expanded polystyrene wrapped with a fiberglass mesh and liquid waterproof membrane finish. Curbs are lightweight and ready-to-tile.
- 1.2 Materials: Utility knife, latex modified thin-set mortar, large headed fastener and polyurethane sealant.

2.0 PREPATORY WORK

- 2.1 Ensure substrate is level and flat prior to beginning.

3.0 INSTALLATION OF CURB OVERLAY

NOTE: Curb Overlay should be installed before installation of mortar bed and after installation of waterproof membrane.

- 3.1 Cut Curb Overlay to dimension of opening.
- 3.2 Coat inside of Curb Overlay with latex modified thin-set mortar and place over pan liner.
- 3.3 Ensure that Curb Overlay is set firmly against curb structure.
- 3.4 After leveling Curb Overlay, secure with large headed fastener on outside of curb structure. Do not compromise inside of curb structure with fasteners.
- 3.5 Apply a bead of polyurethane sealant where Curb Overlay meets the wall/jamb.
- 3.6 Install tile according to Tile Council of North America (TCNA) guidelines.

PreFormed™ Full Foam Curb Installation Instructions

1.0 PRODUCT & MATERIALS

- 1.1 Product: Full Foam Curbs are made from high-density expanded polystyrene and coated with a liquid waterproof membrane finish. Curbs are lightweight and ready-to-tile.
- 1.2 Materials: Utility knife or fine tooth saw, latex modified thin-set mortar and polyurethane sealant.

2.0 PREPATORY WORK

- 2.1 Ensure substrate is level and flat prior to beginning.

3.0 INSTALLATION OF FULL FOAM CURB

- 3.1 Cut Full Foam Curb to dimension of opening.
- 3.2 Apply latex modified thin-set mortar to floor area
- 3.3 Apply latex modified thin-set mortar to bottom and both ends of curb.
- 3.4 Embed curb into thin-set and apply weight to curb to properly seat curb into wet thin-set.
- 3.5 Allow thin-set to cure according to manufactures instructions.
- 3.6 Caulk with polyurethane sealant where curb meets wall/jamb.
- 3.7 Install shower pan per manufactures instructions and TCNA guidelines.
- 3.8 Extend waterproofing membrane up and over curb.
- 3.9 Install tile according to Tile Council of North America (TCNA) guidelines.

For Technical Assistance Call Fin Pan, Inc. at 800-833-6444

*PreFormed Curb Overlay and Full Foam Curb Warranty will be voided if modified on the jobsite other than for cutting product to proper length. Waterproofing should not be compromised. PreFormed Ready-To-Tile Components must be installed per Manufacturer's Instructions.